

HOOK IT UP

WCI10V23

THIS IS A QUICK INSTALL GUIDE - ENSURE ALL WORK IS DONE BY QUALIFIED PERSONNEL

1. PLACEMENT



- Place indoors ONLY.
- Locate on level surface with wheels locked.
- Allow 8" clearance on all sides for proper air flow.

2. ELECTRICAL




- Must conform to Electrical Code.
- Equipped with 2' Cam-Lok cord ends.
- Incorrect phasing indicated by warning light.

3. PLENUM/DUCT



- Ductable up to 75'
- **Straight-** eliminate bunching and hard turns on duct run
- **90'-** can pressurize server room floor
- **Square-** adjust air delivery with louvers

4. WATER HOOK-UP



- Water supply must be capable of 7 gpm.
- Janitors sink will work.
- Cool air can supply the necessary connection hardware.
- Dual check valve available upon request.

5. SUPPLY & RETURN



- Supply: 3/4" BLUE PVC hose ONLY.
- Return: 3/4" BLACK RUBBER hose ONLY.
- Hand tighten - DO NOT use wrenches.
- DO NOT operate unit without supply water turned on.

6. CONDENSATE



- Use 3/8" clear braided water tubing.
- Use two wrenches to secure this tubing.
- Carefully lay and secure condensate to BLACK return hose.
- Secure both hoses to drain assembly.

7. CONTROL OPTIONS



- **Thermostat** - control temperature.
- **Push-Button** - simple ON/OFF Switch.
- **Remote Control** - from 10' to 100' away.
- Please obtain operating instructions for complete details.

8. FILTERS



- DO NOT run without filters in place.
- Inspect filters weekly and clean and/or replace as required.
- To clean - vacuum and/or wash.

9. CONTACT



- These are complex machines.
- Please follow instructions closely for safety and reliability.
- Call Cool Air at any time for more information on installation or operation.